C0260022235 MS305說明書 2015-02-23 DF

Owner's Manual

EN

Classic 4

(MS305)

Read and save this instruction

C0260022235

AN IMPORTANT MESSAGE TO PARENTS:

This manual contains important safety information. For your child's safety, it is your responsibility to review this information with your child and make sure that your child understands all warnings, cautions, instructions and safety topics. Jdbug recommends that you periodically review and reinforce the information in this manual with younger riders. You should also regularly inspect and maintain your child's scooter to insure their safety.

GENERAL WARNING:

The Scooter / Toy shall be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties".

Scooter riding can be hazardous activity. Scooters can, and are intended to move and it is therefore possible to get into dangerous situations and/ or lose control and/ or fall off. If such things occur you can be seriously injured or die.
LIKE ANY OTHER MOVING PRODUCT, USING A SCOOTER CAN BE A DANGEROUS ACTIVITY AND MAY RESULT IN INJURY OR DEATH EVEN WHEN USED WITH PROPER SAFETY PRECAUTIONS. USE AT YOUR OWN RISK AND USE COMMON SENSE.

This is not a toy

- Always wear proper protective equipment, such as an approved helmet, glove, elbow pads, wrister and kneepads. Long sleeve shirt, long pants and lace-up athletic shoes are recommended. Don't ride barefoot or in sandals. Keep shoelaces out of the way of wheels.
- Use the scooter only on flat, dry, level ground without loose debris, such as rocks or gravel.
- Never use the scooter at dusk or night or in wet or icy conditions.
- Warning! Not suitable for children under 3 years due to small part and long cord.
- Avoid water, speed jumps, sand, gravel and anything else that could cause your front wheel to stop. Bumps have the potential to stop the front wheel. When in doubt, avoid the bumps.
- Protective equipment should be worn.
- EN71-3, EN14619 APPROVAL
- Maximum rider weight: 50kg (110 Lbs) Class A
- Please assemble and fold the scooter by adult when it is used by children and preteens.
- Do not allow children under age five (5) to use the scooter. All children and preteens should ride with adult guidance at all times.
- Never ride in traffic or on the street and watch your surroundings for pedestrians, bikes, and skateboard and scooter rides. Use the scooter only in areas free from fixed or moving hazards, such as poles, curbs, hydrants, walls parked automobiles and traffic.

FAILURE TO USE COMMON SENSE AND HEED THE ABOVE WARNINGS FURTHER INCREASES RISK OF SERIOUS INJURY. USE AT YOUR OWN RISK AND WITH APROPRIATE AND SERIOUS ATTENTION TO SAFE OPERATION. USE CAUTION.

- Please read the instruction and use the brake properly.
  Do not touch the brake after use. Brake will be hot after use.
  Please do proper maintenance on bearings.
  After several times maintenance, bolts and nuts may be damaged and broken.
  Replace worn or broken parts immediately
  Parents or carers should ensure that children are properly instructed in the safe use of the braking systems.

WARNING:

ALWAYS INSPECT SCOOTER PRIOR TO RIDING. Properly inspecting and maintaining your scooter can reduce the risk of injury. Always inspect your scooter before riding and regularly maintain it.

WARNING:

REGARDING USE OF NON-JD BUG PRODUCTS WITH YOUR JD BUG SCOOTER. Your scooter has been built to JdBug design specifications. All the original equipments supplied at the time of sale were selected on the basis of their compatibility with the frame, fork and all other parts.
Certain after-market products may or may not compatible with your JdBug Scooter. Unsuitable modification can bring you a hazard! Consult your retailer or call JdBug prior to modifying or replacing any component with a non-factory specified product.

WARNING:

CHECK LOCAL LAWS REGARDING SCOOTER USE. Check local laws and regulations to see where and how you may use your JdBug scooter legally.
In local laws and regulations regarding laws governing helmet use and scooter operation in your area.

1. Scooter Parts and Components



A. Insert and secure the left and right handlebars by pressing the spring-loaded buttons and inserting them into the T-tube. Make certain the spring-loaded button engages the hole in the T-bar for each handlebar .



WARNING:

Failure to properly engage the spring-loaded buttons may cause the handlebars to dislodge while riding and may cause you to lose control and fall. When correctly engaged the handlebars will not rotate nor will they move sideways. Note that when properly engaged, the spring-loaded buttons are clearly visible in the holes on the T-tube.

B. To release the folding mechanism, grasp the T-tube with one hand between the collar clamp and the quick-release clamp and, with the other hand, pull up the joint lever up to release the steering column from the locked position and allow you to pivot it to the upright position.

WARNING:

Keep your fingers clear of the pivoting mechanism when folding or unfolding the scooter. Make sure others are standing clear.

C. The joint lever is spring-loaded and will automatically lock in the upright position when fully upright.

D. To adjust the height of the handlebars, unlock the steering tube by pulling outward on the quick-release lever. Slider the T-tube to the desired position and secure by pushing inward on the quick release clamp.

WARNING:

Failure to properly engage the quick-release clamp may cause the T-tube to telescope up or down while riding which may cause you to lose control and fall. With the quick-release properly adjusted and engaged, the handlebars will not move up or down.

E. The tension of the quick-release clamping mechanism can be adjusted by tightening or loosening the Allen bolt. Be careful not to over-tighten. You should always be able to open and close the quick-release lever by hand and the t-tube should telescope freely with the quick-release open.

3. Check Before Riding

A. Collar Clamp.

Using the correct size Allen wrench, check that the collar clamp bolt is tightened securely (30 to 60 inch-pounds torque). This item is tightened and quality-inspected at the factory, but there is a slight chance that the effects of shipping or handling may have caused this bolt to loosen.

B. Baseboard/Steering Column Adjusting Screw(s).

Using an Allen wrench and with the scooter in the upright and locked position adjust the set screw at the baseboard until there is no free-play between the baseboard and the steering column. Be careful not to over-tighten this screw as it needs only be snug against the steering column. Verify the adjustment by releasing the steering column from the locked position and folding the scooter. The locking latch should not bind and the folding movement should be smooth.

WARNING:

Keep your fingers clear of the pivoting mechanism when folding or unfolding the scooter.

4. Limited Warranty

This Limited Warranty is the only warranty for JdBug scooters. There is no other express or implied warranty. The manufacturer warranties his product to be free of manufacturing defects for a period of six months from date of purchase. This Limited Warranty does not cover normal wear and tear, nor any damage, failure or loss caused by improper assembly, maintenance, storage or use of the scooter.
This Limited Warranty will be void if the product is ever:

a. Used in a manner other than for recreation or transportation:
b. Modified in any way;
c. Rented.

Check local laws and regulations to see where you may ride your scooter legally.
The manufacturer is not liable for incidental or consequential loss or damage due directly or indirectly from the use of this product.

To obtain service under this warranty you must, within the warranty period, contact local distributor or by e-mail through JdBug website www.JdBug.com .
JdBug will provide warranty replacement at its sole discretion.
Specifications subject to change without notice.