



# 10" & 12" Folding Balance Bike

Age 3+ years  
Maximum Weight 50kg




**PLEASE READ THIS MANUAL BEFORE USE**

## Operating Instructions

Remove all the packaging material including plastic protection, foam pieces, elastic bands, ties and any other material that is not part of the product. These should be removed and disposed of out of children's reach


### Folding The Rear Wheel

1. Tap wheel down



2. Rotate until it clicks into place


### Unfolding The Rear Wheel




Pull the rear wheel downwards and rotate until it clicks into place.

### Rotating the Bars Flat

1. Pull the bars up 10-15mm whilst holding the fork, support the bike between your legs




2. From the top, twist the bars anti-clockwise to fold away and clockwise to ride, ensure it clicks into place



## Attaching the Carry/Tow Strap


**To Carry** - Attach the carry strap to both the front and rear clip locations to allow carrying when folded and unfolded

**To Tow** - Attach the carry strap to the front clip location



## Adjusting the Saddle

The saddle height should be set so that the child can place both feet flat on the ground whilst sitting on the saddle, make sure the minimum seat post insertion safety line (a) is inserted within the seat tube. The quick release lever (b) should be tightened properly. You can adjust the screw (c) before locking the lever. The correct clamping force will have been achieved if the lever leaves a temporary white mark on your palm after closing it.



**CHECK THE TIGHTNESS OF ALL SCREWS AND LOCKING DEVICES BEFORE EVERY RIDE**

## ⚠ WARNINGS ⚠

- Adult assembly required, the folding features are designed for adult use only!
- All packaging material must be removed and disposed of before use and kept away from children.
- This product is suitable for 3+ years. **NOT SUITABLE FOR CHILDREN UNDER 36 MONTHS** due to a long cord - strangulation risk.
- Maximum rider weight is 50kg. This toy has no brake.
- 10" bike is for height range 75cm-90cm, 12" bike is for height range 90cm-110cm.
- Always wear helmet, wrist knee and elbow pads when riding.
- Always wear sturdy shoes when riding.
- Never ride on public roads and pavements where there is risk from traffic or pedestrians.
- Never ride at night.
- Only use on flat level ground and avoid surfaces with water, sand, gravel, dirt and other debris.
- Avoid excessive speed associated with steep slopes and downhill riding.
- Children must be under adult supervision at all times when riding.
- Adults must assist children in the adjustment and preparation of the bike before riding.
- CAUTION: Skill is required to avoid falls and collisions that may cause injuries.
- Do not use the bike if it has any damage and replace worn or broken parts with original spare parts immediately.
- Read the information supplied by the manufacturer.

## Maintenance

- Regular maintenance of your bike ensures it stays safe for use.
- Keep the bike in a dry and dust free place.
- Clean with a damp cloth, do not use solvents or bleaches for cleaning.
- Oil the wheel and frame bearings regularly.
- Oil the headset, fork, steering and stem regularly.
- For your safety, please only use original spare parts.
- Do not make any structural changes.
- No modifications other than to the manufacturer's instruction shall be made.

Produced for:  
Trunki  
Shaftesbury Chapel  
Union Road, Bristol  
BS2 0LP  
www.trunki.co.uk  
Trunki is a registered trademark of Magmatic Ltd.  
Imported by: Halfords. B98 0DE